

SPOT LEVEL SAMPLERS

Spot level samplers are ideally suited to draw true spot samples from any level or depth.



Spot level sampler has a valve at the top which can be opened by a snatch on the supporting cable.

Spot level sampler has a valve at the top which can be opened by a snatch on the supporting cable.

The valve stays closed during the operation, and the sampler remains empty until the sampler reaches the depth at which the sample is required.



Samples are obtained uncontaminated and undiluted from samples at any other level in the tank or reservoir.

The top hat design minimises falling out from the supporting cable.

Available in brass and stainless steel with capacities between 130 ml and 2500 ml and diameters between 38 mm and 152 mm.



Model	Capacity	Length	Diameter	Inlet diameter	Material	Sampling height from bottom	Weight
ALS 131	130 ml	23 cm	38 mm	21 mm	Brass	17 cm	0.7 kg
ALS 132	130 ml	23 cm	38 mm	21 mm	Stainless Steel	17 cm	0.7 kg
ALS 451	450 ml	55 cm	38 mm	21 mm	Brass	49 cm	1.1 kg
ALS 452	450 ml	55 cm	38 mm	21 mm	Stainless Steel	49 cm	1.1 kg
ALS 501	500 ml	43 cm	51 mm	23 mm	Brass	37 cm	1.5 kg
ALS 502	500 ml	43 cm	51 mm	23 mm	Stainless Steel	37 cm	1.5 kg
ALS 503	500 ml	31 cm	64 mm	30 mm	Brass	25 cm	1.4 kg
ALS 504	500 ml	31 cm	64 mm	30 mm	Stainless Steel	25 cm	1.4 kg
ALS 542	500 ml	55 cm	42 mm	21 mm	Stainless Steel	47 cm	1.2 kg
ALS 1001	1 litre	48 cm	64 mm	30 mm	Brass	42 cm	2.2 kg
ALS 1002	1 litre	48 cm	64 mm	30 mm	Stainless Steel	42 cm	2.2 kg
ALS 1042	900 ml	92 cm	42 mm	21 mm	Stainless Steel	40 cm	1.8 kg
ALS 1089	1 litre	35 cm	90 mm	30 mm	Stainless Steel	26 cm	2.3 kg
ALS 1501	1.5 litre	46 cm	76 mm	30 mm	Brass	40 cm	2.7 kg
ALS 1502	1.5 litre	46 cm	102 mm	30 mm	Stainless Steel	40 cm	2.7 kg
ALS 2504	2.5 litre	50 cm	102 mm	40 mm	Stainless Steel	40 cm	4.0 kg
ALS 2506	2.5 litre	29 cm	152 mm	40 mm	Stainless Steel	25 cm	4.0 kg